Suite Maintenance Guide

In Case Of A Water Emergency – Note Where Your Shut-off Valves Are

- · Your main shut-off valve is typically located in the main bathroom or ensuite
- Alternate locations may include behind the toilet, laundry or under the kitchen sink

Change/ Clean ALL Your Filters Regularly

- Dryer exhaust ceiling lint trap clean monthly
- Dryer lint trap clean after each use
- Microwave / Hood Fan filter clean monthly
- Fan coil filter replace every 3 to 6 months, or more frequently if anyone in the home smokes
- Energy Recovery Ventilator filters clean every 6 months (Contact your Property Management Team for more information of recommended maintenance programs.)

Managing Condensation – Increase Air Circulation and Adjust Humidity Levels

- Use exhaust fans consistently
- Ensure your ERV unit is turned on and functioning properly
- Periodically open your windows and window coverings

Electrical Issues

- Bathroom or kitchen plugs not working reset GFI button on plug
- Flickering Lights tighten or replace light bulb
- No Power reset breaker
- Lamps not working check switched receptacle

Suite Maintenance While On Vacation

- · Keep your ERV and fan coil running
- Turn off your main water shut-off valve
- Close and lock all windows and doors
- Inform your Property Manager/ Concierge of your absence
- Have a friend or family member check your suite while you are away



Questions or concerns?